

Simple, portable, durable mounting bracket for laser projectors and lighting fixtures



DIMENSIONS: 23.5" x 4.5" x 18.5" (OUTER); 23" x 12" (INNER)*

* Test fixture height with clamps attached when estimating fits
Round bar diameter 2"; bar circumference 6.5"

WEIGHT: 5 lbs (2.3kg)

DETAILS:

The Mobile Mount by X-Laser is a quick, portable and efficient mounting solution built for all types of mobile and semi-permanent install applications. Quickly and easily attach the Mobile Mount to any standard tripod or 40mm mount with absolutely no trussing required. Once attached, simply mount your fixtures to the Mobile Mount with standard O or C clamps for secure attachment. Each X-Laser Mobile Mount can accommodate up to two small lasers such as X-Laser Caliente or Mobile Beat models; one large laser such as the X-Laser X-Beam or Defiant; two medium-sized LED effects; or an endless variety of other lighting fixtures and hardware combinations, up to a combined rigged weight of 60 pounds.

- Use with standard O or C clamps
- Safely holds up to 60lbs in a variety of configurations
- Easily attaches to the top of any 40mm standard speaker stand
- Goes anywhere you can fit a tripod, for maximum versatility
- Rugged aircraft-grade aluminum and power-coated finish for durability